

Isolated 16-bit Voltage Output Phidget

Contents

1 GETTING STARTED

2 USING THE OUT1002

2.1 Phidget Control Panel

2.1.1 Windows

2.1.2 macOS

2.2 First Look

2.3 Voltage Output

3 TECHNICAL DETAILS

- 3.1 Control Application
- 3.2 Transient Voltages
- 3.3 Current Sourcing and Sinking


4 WHAT TO DO NEXT

Getting Started

Welcome to the OUT1002 user guide! In order to get started, make sure you have the following hardware on hand:

- OUT1002 - Isolated 16-bit Voltage Output Phidget
- VINT Hub
- Phidget cable
- USB cable and computer
- something to use with the OUT1002 (e.g. multimeter, oscilloscope, device with voltage input, etc.)

Next, you will need to connect the pieces:



1. Connect the OUT1002 to the VINT Hub using the Phidget cable.
2. Connect the VINT Hub to your computer with a USB cable.

Now that you have everything together, let's start using the OUT1002!

Using the OUT1002

Phidget Control Panel

In order to demonstrate the functionality of the OUT1002, the Phidget Control Panel running on a Windows machine will be used.

The Phidget Control Panel is available for use on both macOS and Windows machines.


Windows

TO
TOP

To open the Phidget Control Panel on Windows, find the  icon in the taskbar. If it is not there, open up the start menu and search for Phidget Control Panel



macOS

To open the Phidget Control Panel on macOS, open Finder and navigate to the Phidget Control Panel in the Applications list. Double click on the  icon to bring up the Phidget Control Panel.


For more information, take a look at the getting started guide for your operating system:

- Getting started with Windows
- Getting started with macOS

Linux users can follow the getting started with Linux guide and continue reading here for more information about the OUT1002.

First Look

After plugging the OUT1002 into your computer and opening the Phidget Control Panel, you will see something like this:




The Phidget Control Panel will list all connected Phidgets and associated objects, as well as the following information:

- **Serial number:** allows you to differentiate between similar Phidgets.
- **Channel:** allows you to differentiate between similar objects on a Phidget.
- **Version number:** corresponds to the firmware version your Phidget is running. If your Phidget is listed in red, your firmware is out of date. Update the firmware by double-clicking the entry.

The Phidget Control Panel can also be used to test your device. Double-clicking on an object will open an example.

Voltage Output

Double-click on the Voltage Output object , labelled Isolated 16-bit Voltage Output Phidget, in order to run the example:




General information about the selected object will be displayed at the top of the window. You can also experiment with the following functionality:

- Set the output voltage by dragging the Voltage slider.
- Select the Voltage Output Range from the drop-down menu. You can choose between 0-5V output or $\pm 10V$ output.

Technical Details

Control Application



Some devices may require an analog voltage as a control input. The OUT1002 supplies a fixed voltage up to $\pm 10V$, which can be used to control such devices.

In addition, this device is isolated and can apply its voltage anywhere in an application circuit, independent of USB ground.

Transient Voltages


The OUT1002 may have an unpredictable output voltage for a very short time immediately after the device changes modes, or is turned on. If this is a problem in your application and you have no way to ignore it via software, we recommend using a solid state relay to switch the output on once it has stabilized.

Current Sourcing and Sinking


To ensure maximum voltage precision across the device's full range, the OUT1002 Phidget should be subjected to a minimal current draw, ideally less than 5mA in $\pm 10V$ mode. 5V mode should only be used to set a voltage in high-impedance applications.

However, in the event you plan to power a small load with this device, it will either be sourcing or sinking current when in use. When it's connected to a circuit with a lower voltage potential than its own voltage setting, current will be flowing out from the OUT1002 into the circuit, so it will be sourcing current. When it's connected to a circuit with a higher voltage potential than the voltage it's set to, current will flow from the circuit into the OUT1002 for a current sinking situation.



Current Sourcing



Current Sinking



The OUT1002 can source or sink up to 26mA of current depending on the selected output voltage and mode. Please refer to the chart below to determine the amount of current that can be sourced or sunk.



For example, if the connected circuit is pulling 25mA of current, the OUT1002 will only be able to provide a maximum of 2V (in 0-5V mode), even if you try to set it to a higher value.

What to do Next

- [Software Overview](#) - Find your preferred programming language here to learn how to write your own code with Phidgets!
- [General Phidget Programming](#) - Read this general guide to the various aspects of programming with Phidgets. Learn how to log data into a spreadsheet, use Phidgets over the network, and much more.
- [Phidget22 API](#) - The API is a universal library of all functions and definitions for programming with Phidgets. Just select your language and device and it'll give you a complete list of all properties, methods, events, and enumerations that are at your disposal.