

1016 User Guide



Go to this device's product page ^[1]

Getting Started

Checking the Contents

You should have received:

- A PhidgetCircularTouch board.
- A custom USB cable

Connecting the Pieces

1. Connect the PhidgetCircularTouch board to the computer using the included custom USB cable.



Testing Using Windows 2000 / XP / Vista / 7

Make sure you have the current version of the Phidget library installed on your PC. If you don't, follow these steps:

1. Go to the Quick Downloads section on the Windows page
2. Download and run the Phidget21 Installer (32-bit, or 64-bit, depending on your system)
3. You should see the **Ph** icon on the right hand corner of the Task Bar.

Running Phidgets Sample Program


Double clicking on the **Ph** icon loads the Phidget Control Panel; we will use this program to ensure that your new Phidget works properly.

The source code for the **InterfaceKit-full** sample program can be found in the quick downloads section on the C# Language Page. If you'd like to see examples in other languages, you can visit our Languages page.

Updating Device Firmware

If an entry in this list is red, it means the firmware for that device is out of date. Double click on the entry to be given the option of updating the firmware. If you choose not to update the firmware, you can still run the example for that device after refusing.

Double Click on the  icon to activate the Phidget Control Panel and make sure that the Phidget Touch Rotation is properly attached to your PC.



1. Double Click on Phidget Touch Rotation in the Phidget Control Panel to bring up InterfaceKit-full and check that the box labelled Attached contains the word True.
2. As you bring your finger closer to the board and touch the board, tick marks will appear in the Digital In boxes. The left one shows "touch" and the right one shows "proximity".
3. Move your finger along the backside of the PhidgetCircularTouch and watch the numbers in the Analog box change. The numbers are only significant when both Digital In boxes are "tick marked".
4. Adjusting the input sensitivity with the sensitivity slider changes the number of discrete steps that will fire the on-sensor-change event.

Testing Using Mac OS X

1. Go to the Quick Downloads section on the Mac OS X page
2. Download and run the Phidget OS X Installer
3. Click on System Preferences >> Phidgets (under Other) to activate the Preference Pane
4. Make sure that the Phidget Touch Rotation is properly attached.
5. Double Click on Phidget Touch Rotation in the Phidget Preference Pane to bring up the InterfaceKit-full Sample program. This program will function in a similar way as the Windows version.

Using Linux

For a step-by-step guide on getting Phidgets running on Linux, check the Linux page.

Using Windows Mobile / CE 5.0 / CE 6.0

For a step-by-step guide on getting Phidgets running on Windows CE, check the Windows CE page.

Technical Details

Device Inputs

The PhidgetCircularTouch appears to the Phidget software libraries as an InterfaceKit. Sliding a finger around the touch sensor varies the Analog Input 0 value from 0 to 1000 in approximately 125 discrete steps. When the finger is removed, the final measured value is retained. Two Digital Inputs are also utilized to convey additional information: Digital Input 0 appears True when contact is made with the electrodes on the Phidget, and Digital Input 1 appears True when a finger or contacting object comes in close proximity to the electrodes. The two Digital Inputs are intended to be used as a quality measure, allowing the developer to trust the Analog Input value only when both Digital Inputs are true.

Input	Range	Description
Analog Input 0	0 - 1000	Analog value representing touch position
Digital Input 0	True/False	True indicates physical contact with electrode
Digital Input 1	True/False	True indicates proximity to electrodes

If it is desired to use the touch slider as an array of buttons, or a combination of an array of buttons and a smaller slide-touch area, one must only interpret specific sub-ranges of sensor values differently in software depending upon the intended use. If sub-ranges of values are to be used as buttons, it is recommended that a small range of sensor values be left between the sub-ranges where a null-response is observed.

Dielectric Separation

The PhidgetCircularTouch has been left without components on the contact side so that it may be mounted behind a sheet of glass or plastic. The recommended thickness of separation material is 1/8 inch. Silicon adhesive is recommended when attaching the Phidget to the material; standing the PhidgetCircularTouch off or creating space between the separation material and the Phidget can cause false-triggering to occur.

It should be noted that materials thicker than 1/8" may work, but will require a larger surface area of contact to ensure proper triggering (i.e.: two fingers instead of one). Increasing the surface area of the contacting object helps to increase the measurable capacitance at the point of contact that further separation causes to reduce, balancing these factors out.

API

We document API Calls specific to this product in this section. Functions common to all Phidgets and functions not applicable to this device are not covered here. This section is deliberately generic. For calling conventions under a specific language, refer to the associated API manual in the Quick Downloads section for that language. For exact values, refer to the device specifications.

Functions

int InputCount() [get] : Constant = 2

Returns the number of digital inputs supported. Please refer to the Device Inputs section for details on the abstractions used on the 1016.

bool InputState(int InputIndex) [get]

Returns the state of a particular digital input.

int SensorCount() [get] : Constant = 1

Returns the number of sensors (Analog Inputs) supported by this PhidgetInterfaceKit. Interpreted together with the digital inputs, this represents the position of the user's finger on the circular slider.

int SensorValue(int SensorIndex) [get]

Returns the sensed value of a particular Analog Input. Please refer to the Device Inputs section for details on the abstractions used on the 1016.

double SensorChangeTrigger (int SensorIndex) [get,set]

Returns the change trigger for an analog input. This is the amount that an inputs must change between successive SensorChangeEvents. This is based on the 0-1000 range provided by getSensorValue. This value is by default set to 10.

Events

OnInputChange(int InputIndex, bool State) [event]

An event that is issued when the state of a digital input changes.

OnSensorChange(int SensorIndex, int SensorValue), [event]

An event that is issued when the returned value from an Analog Input varies by more than the SensorChangeTrigger property.

Product History

Date	Board Revision	Device Version	Comment
August 2005	0	100	Product Release
January 2006	0	101	Design migrated to Encore II processor
January 2007	0	102	Bus reset/low voltage reset defined

References

[1] http://www.phidgets.com/products.php?product_id=1016

Article Sources and Contributors

1016 User Guide *Source:* http://www.phidgets.com/wiki/index.php?title=1016_User_Guide *Contributors:* Burley, Mparadis

Image Sources, Licenses and Contributors

Image:1016.jpg *Source:* <http://www.phidgets.com/wiki/index.php?title=File:1016.jpg> *License:* unknown *Contributors:* Mparadis

File:1016_0_Connecting_The_Hardware.jpg *Source:* http://www.phidgets.com/wiki/index.php?title=File:1016_0_Connecting_The_Hardware.jpg *License:* unknown *Contributors:* Mparadis

File:Ph.jpg *Source:* <http://www.phidgets.com/wiki/index.php?title=File:Ph.jpg> *License:* unknown *Contributors:* Mparadis

File:1016_0_Control_Panel_Screen.jpg *Source:* http://www.phidgets.com/wiki/index.php?title=File:1016_0_Control_Panel_Screen.jpg *License:* unknown *Contributors:* Mparadis

File:1016_0_InterfaceKit_Screen.jpg *Source:* http://www.phidgets.com/wiki/index.php?title=File:1016_0_InterfaceKit_Screen.jpg *License:* unknown *Contributors:* Mparadis